


**PARTS FOR BUTTON HOLE KNIVES**



**FOR BROTHER**


- 109837-0-01 3/8"
- 107204-0-01 7/16"
- 107200-0-01 1/2"
- S03278-0-01 9/16"
- 107205-0-01 5/8"
- 107207-0-01 3/4"
- 109838-0-01 7/8"
- 107210-0-01 1"

**FOR JUKI**

- B2702-047-FOO 1/4"
- B2702-047-GOO 5/16"
- B2702-047-KOO 3/8"
- B2702-047-IOO 7/16"
- B2702-047-LOO 1/2"
- B2702-047-VOO 9/16"
- B2702-047-MOO 5/8"
- B2702-047-NOO 3/4"
- B2702-047-POO 7/8"
- B2702-047-QOO 1"
- B2702-047-ROO 1-1/8"
- B2702-047-SOO 1-1/4"
- B2745-774-OOA 1-3/8"

**FOR SINGER**

- 23443 1/4"
- 23444 5/16"
- 23445 3/8"
- 23446 7/16"
- 23447 1/2"
- 23448 9/16"
- 23449 5/8"
- 23450 11/16"
- 23451 3/4"
- 23453 7/8"
- 23455 1"
- 23457 1-1/8"
- 23459 1-1/4"
- 39566 1-3/8"



**FOR BROTHER**


- 151837-0-01 (3/8")
- 151838-0-01 (7/16")
- 151839-0-01 (1/2")
- S03279-0-01 (9/16")
- 151840-0-01 (5/8")
- 151841-0-01 (3/4")
- 153340-0-01 (7/8")
- 159722-0-01 (1")

**FOR JUKI**

- B2745-771-KOO 3/8"
- B2745-771-IOO 7/16"
- B2745-771-LOO 1/2"
- B2745-771-VOO 9/16"
- B2745-771-MOO 5/8"
- B2745-771-NOO 3/4"
- B2745-771-POO 7/8"
- B2745-771-QOO 1"

**FOR SINGER**

- 71-90 3/8"
- 71-90 7/16"
- 71-90 1/2"
- 71-90 9/16"
- 71-90 5/8"
- 71-90 3/4"
- 71-90 7/8"
- 71-90 1"



**FOR JUKI**

- B2701-180-FOO 1/4" (B2701-180-AOO 1/4")
- B2701-180-KOO 3/8" (B2701-180-BOO 3/8")
- B2701-180-LOO 1/2" (B2701-180-COO 1/2")
- B2701-180-VOO 9/16" (B2701-180-DOO 9/16")
- B2701-180-MOO 5/8" (B2701-180-EOO 5/8")
- B2701-180-NOO 3/4"
- B2701-180-POO 7/8" (B2701-180-GOO 7/8")
- B2701-180-QOO 1" (B2701-180-HOO 1")
- B2701-180-ROO 1-1/8" (B2701-180-JOO 1-1/8")
- B2701-180-SOO 1-1/4"
- B2701-180-TOO 1-3/8"









**FOR REECE**

- S356N 1/8"
- S356N 1/4"
- S356N 5/16"
- S356N 3/8"
- S356N 7/16"
- S356N 1/2"
- S356N 9/16"
- S356N 5/8"
- S356N 11/16"
- S356N 3/4"
- S356N 7/8"
- S356N 1"
- S356N 1-1/8"
- S356N 1-1/4"
- S356N 1-3/8"


KNIVES PARTS FOR BROTHER

 S28352-0-01 LOWER KNIFE	 S09101-0-01 LOWER KNIFE	 S09093-0-01 UPPER KNIFE(RIGHT)	 S09094-0-01 UPPER KNIFE(LEFT)	 S28348-0-01 UPPER KNIFE
 S28650-2-01 MOVABLE KNIFE	 S28654-0-01 FIXED KNIFE	 S16413-0-01 KNIFE	 S07526-3-01 MOVABLE KNIFE	 S29437-0-01 FIXED KNIFE
 S29797-2-01 MOVABLE KNIFE	 SA1360-1-01 KNIFE	 159541-0-01 MOVABLE KNIFE	 S45900-1-01 FIXED KNIFE	 159799-0-01 MOVABLE KNIFE
 S01584-0-01 THREAD RETAINER "B"	 SA3330-1-01 MOVABLE KNIFE ASSY	 SA7944-0-01 FIXED KNIFE	 SA3656-0-01 MOVABLE KNIFE ASSY	 SA3658-0-01 FIXED KNIFE
 S49988-0-01 MOVABLE KNIFE	 S10210-2-01 FIXED KNIFE	 S57670-0-01 FIXED KNIFE	 S37723-0-01 UPPER MOVABLE KNIFE	 S35029-0-01 UPPER MOVABLE KNIFE
 S20118-0-01 CHAIN CUTTER	 S48006-0-01 FACE PLATE KNIFE	 SA6989-0-01 MOVABLE KNIFE (L)	 SA6988-0-01 MOVABLE KNIFE ®	 S34899-0-01 MOVABLE KNIFE ASSY



















KNIVES PARTS FOR BROTHER

 S34895-0-01 LOWER KNIFE	 S37671-1-01 MOVABLE KNIFE,L 22-26MM	 S37675-1-01 MOVABLE KNIFE,R 22-26MM	 S37672-1-01 MOVABLE KNIFE,L 26-30MM	 S37676-1-01 MOVABLE KNIFE,R 26-30MM
 S34900-0-01 OPENER, T-NIPPER	 S19824-0-01 UPPER THREAD TRIMMER ASSY		 S50404-3-01 S50404-4-01 UPPER THREAD TRIMMER ASSY	
 S50258-1-01 LOWER THREAD RETAINER	 S50259-1-01 LOWER FIXED KNIFE UNIT	 141541-1-01 MOVABLE KNIFE	 S56370-0-01 MOVABLE KNIFE	 S56368-0-01 LOWER THREAD RELEASES
 S55863-0-01 MOVABLE KNIFE	 S58943-0-01 MOVABLE KNIFE, H	 SA8459-0-01 FIXED KNIFE	 S21230-0-01 MOVABLE KNIFE	 S21233-0-01 FIXED KNIFE
 S21253-0-01 MOVABLE KNIFE	 S21252-0-01 FIXED KNIFE	 S36625-0-01 LOWER THREAD FINGER	 030-0095-00 KNIFE NA 14-24, LEFT	 030-0096-00 KNIFE NA 14-24, RIGHT
 030-0097-00 KNIFE NA 8-12, LEFT	 030-0098-00 KNIFE NA 8-12, RIGHT	 030-0461-00 CENTER KNIFE	 S08302-0-01 KNIFE (L)	 S08322-0-01 KNIFE (R)
















KNIVES PARTS FOR BROTHER

					
112436-0-01 LOWER KNIFE	118527-0-01 LOWER KNIFE	S20582-0-01(T=1.5) S20899-0-01(T=1.0) LOWER KNIFE	S20583-0-01 LOWER KNIFE	X05007-0-01 LOWER KNIFE	127734-0-01 UPPER KNIFE
					
148198-0-01 UPPER KNIFE	144074-0-00 UPPER KNIFE	144074-3-00 UPPER KNIFE	140242-0-01 UPPER KNIFE	148342-0-01 UPPER KNIFE	148815-0-01 UPPER KNIFE
					
S20579-1-01 ANGLE KNIFE	S20896-1-01 ANGLE KNIFE	S20897-1-01 ANGLE KNIFE	S20898-1-01 ANGLE KNIFE	140888-0-01 TRIMMING KNIFE	148259-0-01 TRIMMING KNIFE
					
S02375-0-01 MOVABLE KNIFE ASM.	S02374-0-01 FIXED KNIFE	S10205-0-01 MOVABLE KNIFE	S10210-0-01 FIXED KNIFE	142061-0-01 FIXED KNIFE	145608-0-01 MOVABLE KNIFE
					
152901-0-01 MOVABLE KNIFE	152905-0-01 FIXED KNIFE	141541-0-01 MOVABLE KNIFE	141543-0-01 FIXED KNIFE	159274-0-01 MOVABLE KNIFE	159276-0-01 FIXED KNIFE
					
S00706-2-01 MOVABLE KNIFE	S00713-0-01 FIXED KNIFE	141509-0-01 UPPER THREAD TRIMMING ASSEMBLY		159357-0-01 UPPER THREAD TRIMMING ASSEMBLY	

**KNIVES PARTS FOR BROTHER**

					
154568-0-01 FIXED KNIFE	154575-0-01 MOVABLE KNIFE	159540-0-01 FIXED KNIFE	159915-0-01 MOVABLE KNIFE	S02637-0-01 FIXED KNIFE	S02645-0-01 MOVABLE KNIFE
					
S03627-0-01 MOVABLE KNIFE	S03629-0-01 FIXED KNIFE	111114-0-01 THREAD CUTTER	111113-0-01 THREAD CUTTER GUIDE PLATE	S10605-0-01 COUNTER KNIFE	S16248-0-01 COUNTER KNIFE
					
148538-0-01 FIXED KNIFE , LEFT	149169-0-01 FIXED KNIFE , RIGHT	148535-0-01 MOVABLE KNIFE	S07527-0-01 FIXED KNIFE	S07526-0-01 MOVABLE KNIFE	S07526-2-01 MOVABLE KNIFE

**KNIVES PARTS FOR DURKOPP**

				
211-50366 UNDER TRIMMER KNIFE	211-9677 (219-6708A) UNDER TRIMMER KNIFE	227-683 KNIFE 227-683-TI KNIFE	244-14157 KNIFE	246-2553 KNIFE 246-2553-TI KNIFE
				
558-2562 KNIFE	558-2564 KNIFE	558-6109 UPPER KNIFE	558-6110 LOWER KNIFE	570-974 COUNTER KNIFE
				
578-3365 KNIFE	746-60689 KNIFE	746-60690 KNIFE	746-60692 KNIFE	746-60691 KNIFE

KNIVES PARTS FOR DURKOPP

 0745-339100 KNIFE	 0745-339110 KNIFE	 0745-339120 KNIFE	 0745-339130 KNIFE	 0745-339320 KNIFE
 227-682 (0227-000682) UPPER KNIFE	 227-683 (0227-000683) UPPER KNIFE	 265-2197 (0265-002197) LOWER KNIFE	 271-1483 (0271-001483) MOVABLE KNIFE	 271-1497 (0271-001497) FIXED KNIFE
 0281-350300 MOVABLE KNIFE	 0281-350310 FIXED KNIFE	 0281-170210 TEAR OFF KNIFE	 51009080 MOVING KNIFE	 5100912 FIXED KNIFE
 558-9011 (0558-009011) MOVABLE KNIFE	 625780 FIXED KNIFE	 625790 MOVING KNIFE		 396-351690 MOVABLE KNIFE
 568-350050 MOVABLE KNIFE	 58110700000 FIXED KNIFE	 58111000000 MOVABLE KNIFE	 0367-350070 MOVABLE KNIFE	 0367-355050 FIXED KNIFE
 0667-355110 MOVABLE KNIFE	 0667-355130 FIXED KNIFE	 0667-355140 FIXING CLAMP	 0767-350380 MOVABLE KNIFE	 0767-350580 FIXED KNIFE

KNIVES PARTS FOR JUKI

 131-50701 LOWER KNIFE	 400-38091 LOWER KNIFE	 400-42378 LOWER KNIFE	 134-60803 LOWER KNIFE	 124-45508 UPPER KNIFE
 131-50602 UPPER KNIFE	 131-50503 UPPER KNIFE	 400-38754 UPPER KNIFE	 400-39364 UPPER KNIFE	 129-22704 CHAIN CUTTER BLADE
 MAT-00505-000 KNIFE	 B4121-522-000(W) KNIFE (WIDE)	 305-00300 LOWER KNIFE	 D2401-530-DOO THREAD TRIMMER KNIFE	 D2404-530-DOO THREAD SPREADER
 400-89755 FIXED KNIFE	 113-13053 MOVING KNIFE ASSEMBLY	 400-44189 THREAD GUIDE FOR KNIFE	 400-50589 FIX KNIFE H	 138-81255 MOVING KNIFE
 110-40508 FORKED BASE FOR KNIFE	 D2423-141-EOO MOVING KNIFE	 D2424-141-EOO COUNTER KNIFE	 113-51400 MOVING KNIFE	 113-51509 COUNTER KNIFE
 235-06009 CLOTH CUTTING KNIFE	 235-06108 THROAT PLATE KNIFE	 225-57557 DRIVING KNIFE ASM.	 225-57706 FIXED KNIFE	 100-01709 TAKE-UP THREAD CUTTER

KNIVES PARTS FOR JUKI




































 <p>G5649-116-AOA CENTER KNIFE</p>	 <p>164-01002 FIXED KNIFE</p>	 <p>164-03008 FIXED KNIFE (R)</p>	 <p>164-18600 MIDDLE KNIFE</p>	 <p>400-26155 KNIFE, RIGHT A</p>
 <p>164-09906 NEEDLE THREAD COUNTER KNIFE</p>	 <p>400-33814 NEEDLE THREAD KNIFE</p>	 <p>400-34923 MOVING KNIFE ASM.</p>	 <p>320-20919 UPPER KNIFE LOWER COVER</p>	 <p>320-18012 MOVING KNIFE</p>
 <p>320-20703 THREAD HAUL PLATE</p>	 <p>320-16107 LOWER THREAD CUTTING KNIFE</p>	 <p>320-23319 THREAD CUTTING KNIFE</p>	 <p>320-20505 THREAD CUTTER LOWER KNIFE</p>	 <p>400-15996 THREAD CUTTER UPPER KNIFE</p>
 <p>320-18509 FIXING KNIFE</p>	 <p>B1528-380-OAO THREAD KNIFE ASM.</p>	 <p>400-29004 FIXED KNIFE</p>	 <p>137-31161 NEEDLE THREAD TRIMMER ASSY.</p>	 <p>400-04255 UTT TRIMMER ASSY.</p>
 <p>400-04311 BT TRIMMER</p>	 <p>137-35469 BOBBIN THREAD TRIMMER CONNEX.</p>	 <p>107-26305 MOVING KNIFE</p>	 <p>213-89200 MOVING KNIFE</p>	 <p>213-89309 FIXED KNIFE</p>
 <p>400-12403 DRIVING KNIFE</p>	 <p>400-12404 FIXED KNIFE</p>	 <p>226-55302 COUNTER KNIFE</p>	 <p>228-20302 COUNTER KNIFE,G</p>	 <p>102-11605 MOVING KNIFE</p>















KNIVES PARTS FOR JUKI

					
115-66502 LOWER KNIFE	118-46003 LOWER KNIFE	118-47605 LOWER KNIFE , CARBIDE	122-20307 LOWER KNIFE	124-47504 LOWER KNIFE	205-9102-01A LOWER KNIFE , CARBIDE
					
405-9102-01A LOWER KNIFE	408-9102-01A LOWER KNIFE	B4118-804-000 LOWER KNIFE	B4118-804-00B LOWER KNIFE , WIDE	B4118-804-00C LOWER KNIFE	B4122-352-00A LOWER KNIFE
					
118-45609 UPPER KNIFE	118-45708 UPPER KNIFE	118-47407 UPPER KNIFE	118-47506 UPPER KNIFE	120-04909 UPPER KNIFE	205-9101-01A UPPER KNIFE
					
405-9101-01A UPPER KNIFE , CARBIDE	408-9101-01B UPPER KNIFE	428-9101-01B UPPER KNIFE	B4108-352-00B UPPER KNIFE	B4108-352-00B(L) UPPER KNIFE	B4108-352-00D UPPER KNIFE , CARBIDE
					
115-65900 UPPER KNIFE	118-45807 UPPER KNIFE	118-45906 UPPER KNIFE	B4111-804-00A UPPER KNIFE	B4111-804-00C UPPER KNIFE	B4111-804-00E UPPER KNIFE
					
MAT-02204-000 FIXED KNIFE	MAT-02203-000 MOVABLE KNIFE	MAT-03505-000 FIXED KNIFE	MAT-03506-000 MOVABLE KNIFE	MAT-03605-00A FIXED KNIFE	MAT-03606-000 MOVABLE KNIFE













KNIVES PARTS FOR JUKI

					
115-21903 CHAIN KNIFE	124-19602 CHAIN KNIFE	B1528-804-000A THREAD TRIMMER	B1530-352-000 THREAD KNIFE	110-40052 MOVING KNIFE	110-93259 MOVING KNIFE
					
114-09257 MOVING KNIFE	B2421-205-OAO MOVING KNIFE	B2421-210-AAO MOVING KNIFE	B2421-210-000 MOVING KNIFE	B2421-280-OAO MOVING KNIFE	D2402-415-BAO MOVING KNIFE
					
D2402-555-BAB MOVING KNIFE	D2402-555-BAO MOVING KNIFE	B2424-210-AOO COUNTER KNIFE	B2424-210-000 COUNTER KNIFE	B2424-280-000 COUNTER KNIFE	114-09604 COUNTER KNIFE
					
1. B2001-761-OAO	B2406-761-OAO BOBBIN THREAD TRIMMER BLADE ASM.	B2408-761-000 COUNTER KNIFE	D2406-555-BOO COUNTER KNIFE	D2406-555-DOH COUNTER KNIFE	
					
2. B2001-762-OAO	B2001-771-OAO NEEDLE THREAD TRIMMER ASM.	B2406-771-OAO BOBBIN THREAD TRIMMER BLADE ASM.	B2408-771-000A COUNTER KNIFE	102-11100 (102-11118) MOVING KNIFE	
					
3. B2001-763-OAO	B1130-026-000 CHAIN CUTTER BLADE (A)	B1131-026-000 CHAIN CUTTER BLADE (B)	102-11209 COUNTER KNIFE	102-32403 COUNTER KNIFE	
					
B2406-373-OAO MOVING KNIFE ASM.	B2410-373-000 COUNTER KNIFE				







**KNIVES PARTS FOR JUKI**

 B4001-180-000 THREAD TRIMMER KNIFE	 B4121-522-000 COUNTER KNIFE	 B4121-052-A00 COUNTER KNIFE	 B4145-530-B00 COUNTER KNIFE	 1. 164-16109 2. 164-18709 KNIFE	 1. 166-07301-A1 2. 166-07400-A2 KNIFE
 166-07509-B1 KNIFE	 166-07608-B2 KNIFE	 166-07707-C1 KNIFE	 166-07806-C2 KNIFE	 1. MAS-11012-000 2. MAS-11013-000 KNIFE	 1. MAS-11017-000 2. MAS-11016-000 KNIFE







**KNIVES PARTS FOR KANSAI SPECIAL**

 07-125 LOWER KNIFE	 07-124 UPPER KNIFE	 07-169 LOWER KNIFE	 07-168 UPPER KNIFE 07-170 UPPER KNIFE, CARBIDE	 07-206 LOWER KNIFE	 07-406 UPPER KNIFE
 07-507 LOWER KNIFE	 07-505 UPPER KNIFE	 1. 07-702 UPPER KNIFE 2. 07-703 UPPER KNIFE 3. 07-707 LOWER KNIFE		 ACE (BK-10KS) KNIFE SET	
 07-558 LOWER KNIFE	 07-570 UPPER KNIFE				
























**KNIVES PARTS FOR KINGTEX**

 6031218P700 LOWER KNIFE	 6031314C500 UPPER KNIFE	 G6050114P700 LOWER KNIFE	 G6050113C500 UPPER KNIFE	 6031002D700 THREAD TRIMMER	 G6050122D700 THREAD TRIMMER
-------------------------------------------------------------------------------------------------------------------	-------------------------------------------------------------------------------------------------------------------	--------------------------------------------------------------------------------------------------------------------	--------------------------------------------------------------------------------------------------------------------	------------------------------------------------------------------------------------------------------------------------	-------------------------------------------------------------------------------------------------------------------------







**KNIVES PARTS FOR MERROW**

					
6-90 UPPER KNIFE (NARROW) 6-90D UPPER KNIFE (WIDE)	6-90-G UPPER KNIFE (NARROW) A-90-3 UPPER KNIFE	6-91 LOWER KNIFE (NARROW)	6-91-E 6-91-K LOWER KNIFE (WIDE)	A-90-7 TOP KNIFE	A-121-1 THREAD CATCHER

**KNIVES PARTS FOR MITSUBISHI**

					
MF 00A0 834 MOVABLE KNIFE	MF 00A0 838 FIXED KNIFE	MF 02A0 834 MOVABLE KNIFE	MF 02A0 838 FIXED KNIFE	MG 52A0 834 MOVABLE KNIFE	MG 52A0 838 FIXED KNIFE
					
MS 01A0 838 FIXED KNIFE	MS 01B0 838 MOVABLE KNIFE	MS 03A0 838 FIXED KNIFE	MS 03B0 838 MOVABLE KNIFE	MS 14A0 838 FIXED KNIFE	MS 03B0 838 MOVABLE KNIFE
					
MF 40A1 834 KNIFE (LEFT)	MF 40A2 835 KNIFE (RIGHT)	MG 40B0 834 KNIFE (LEFT)	MG 40B0 835 KNIFE (RIGHT)	MN 50A0 838 FIXED BLADE	MP 41B0 838 MOVABLE KNIFE
					
MP 41A0 838 FIXED BLADE	MP 41B0 838 MOVABLE KNIFE	MF 90B0 838 MOVABLE KNIFE	MF 90B2 838 MOVABLE KNIFE	MG 44B0 838 MOVABLE KNIFE	MF 90A0 838 FIXED KNIFE






**KNIVES PARTS FOR NEWLONG**

					
246061 MOVING KNIFE	246071 FIXED KNIFE	247011 MOVING KNIFE	247001 FIXED KNIFE	286081 MOVING KNIFE	286091 FIXED KNIFE



KNIVES PARTS FOR PEGASUS

					
137562 LOWER KNIFE	200959 LOWER KNIFE	201127 (THIN) LOWER KNIFE	202295 LOWER KNIFE	202295 (B) LOWER KNIFE	204161 LOWER KNIFE
					
204161A LOWER KNIFE	204351 LOWER KNIFE , CARBIDE	213108 LOWER KNIFE	236608 LOWER KNIFE	277009 LOWER KNIFE	138559 UPPER KNIFE
					
236606 236618 UPPER KNIFE	200971 UPPER KNIFE	201121A UPPER KNIFE	201121ANS UPPER KNIFE	202527A UPPER KNIFE (NARROW)	205258 UPPER KNIFE
					
202570 UPPER KNIFE	277000 FLAT KNIFE	210755 ANGLED KNIFE	211662 211662A ANGLED KNIFE	201308 CHAIN CUTTER KNIFE	202451 CHAIN CUTTER KNIFE
					
179458-05 FIXED BLADE	179459-05 MOVABLE BLADE	301006 FIXED BLADE	301008 MOVABLE BLADE	301035 FIXED BLADE	301036 MOVABLE BLADE
					
1. 257573 UPPER KNIFE 2. 257573A UPPER KNIFE 3. 257574 UPPER KNIFE 4. 306394 UPPER KNIFE	1. 350024 LOWER KNIFE 2. 350018-91 UPPER KNIFE		1. 350218 UPPER KNIFE 2. 350220 LOWER KNIFE		

**KNIVES PARTS FOR PFAFF**

 <p>91-171153-05 91-175540-05 (NEW) THREAD CATCHER</p>	 <p>91-171853-15 COUNTER KNIFE</p>	 <p>91-169239-14/1 91-169239-14/7 91-169239-14/8 COUNTER KNIFE</p>	 <p>91-168499-05 THREAD CATCHER</p>	 <p>91-168498-05 KNIFE</p>
-------------------------------------------------------------------------------------------------------------------------------------------------	-------------------------------------------------------------------------------------------------------------------------	-----------------------------------------------------------------------------------------------------------------------------------------------------------------	---------------------------------------------------------------------------------------------------------------------------	-------------------------------------------------------------------------------------------------------------------

**KNIVES PARTS FOR REECE**

 <p>10-3072-1-012 (C72-2N-LE) KNIFE WITH SMALL EYE 2"</p>	 <p>10-3072-1-024 (C72-1-1/4RJ-RE) KNIFE WITH REGULAR EYE 1-1/4"</p>	 <p>17-0064-5-950 EYE KNIFE , CB</p>	 <p>20-0094 (S2-94) THREAD TRIMMER KNIFE</p>	 <p>1. 40-0127-1-000 TAB KNIFE 2. 42-0012-0-045 CENTER KNIFE</p>	 <p>46-1125-5-000 KNIFE</p>
--------------------------------------------------------------------------------------------------------------------------------------------------------	-------------------------------------------------------------------------------------------------------------------------------------------------------------------	---------------------------------------------------------------------------------------------------------------------------	-------------------------------------------------------------------------------------------------------------------------------------------	-----------------------------------------------------------------------------------------------------------------------------------------------------------------	--------------------------------------------------------------------------------------------------------------------


















**KNIVES PARTS FOR SINGER**

 <p>164037 LOWER KNIFE</p>	 <p>164728 164233 LOWER KNIFE</p>	 <p>164813 CT164728 LOWER KNIFE , CARBIDE</p>	 <p>410295 LOWER KNIFE</p>	 <p>412749 LOWER KNIFE</p>	 <p>42309 LOWER KNIFE</p>
 <p>164809 UPPER KNIFE, CARBIDE</p>	 <p>412544 412585 UPPER KNIFE, CARBIDE</p>	 <p>42305 UPPER KNIFE</p>	 <p>164026 UPPER KNIFE , NARROW</p>	 <p>164308 UPPER KNIFE , WIDE</p>	 <p>164550 UPPER KNIFE , NARROW</p>
 <p>164556 UPPER KNIFE , WIDE SERRATED</p>	 <p>544599 (SYE)(0.12X0.18) BUTTONHOLE CUTTING KNIFE</p>	 <p>548886 (EYE)(0.12X0.18) BUTTONHOLE CUTTING KNIFE</p>	 <p>548935 (EYE)(0.126X0.18) BUTTONHOLE CUTTING KNIFE</p>	 <p>548936 (EYE)(0.100X0.157) BUTTONHOLE CUTTING KNIFE</p>	 <p>411088 THREAD CUTTER</p>
 <p>239367 KNIFE,STATIONARY</p>	 <p>239372 NEEDLE THREAD KNIFE</p>	 <p>55459 SHUTTLE THREAD KNIFE</p>	 <p>499920 STATIONARY KNIFE</p>	 <p>499919 MOVABLE KNIFE</p>	 <p>413089 MOVABLE KNIFE</p>







KNIVES PARTS FOR RIMOLDI

 202142-0-10 (270-112) UPPER KNIFE	 202143-0-10 (270-112/1) UPPER KNIFE	 202932-0-10 (276B-112) UPPER KNIFE	 203010-0-10 (277-112) UPPER KNIFE	 203066-0-10 (279-112) UPPER KNIFE	 203759-0-10 (2777-112) UPPER KNIFE
 207000-2-00 (CT270-112) UPPER KNIFE, CARBIDE	 CT270-112/1 UPPER KNIFE, CARBIDE	 207001-2-00 (CT276B-112) UPPER KNIFE, CARBIDE	 207002-2-00 (CT277-112) UPPER KNIFE, CARBIDE	 207006-2-00 (CT279-112) UPPER KNIFE, CARBIDE	 207004-2-00 (CT2777-112) UPPER KNIFE, CARBIDE
 203783-0-10 (2777-1121) (290-112) UPPER KNIFE	 202146-0-10 (270-113/1) LOWER KNIFE	 203012-0-10 (277-113) LOWER KNIFE	 203069-0-10 (279-113/1) LOWER KNIFE	 203144-0-10 (2701P9-113/1) LOWER KNIFE	 204693-0-10 (290-113) LOWER KNIFE
 207003-2-00 (CT290-112) UPPER KNIFE, CARBIDE	 207015-2-00 (CT270-113/1) LOWER KNIFE, CARBIDE	 207016-2-00 (CT277-113) LOWER KNIFE, CARBIDE	 207017-2-00 (CT279-113/1) LOWER KNIFE, CARBIDE	 207024-2-00 (CT2701P9-113/1) LOWER KNIFE, CARBIDE	 207020-2-00 (CT290-113) LOWER KNIFE, CARBIDE
 204693-0-11 (290-113SP) LOWER KNIFE	 CT290-113SP LOWER KNIFE, CARBIDE	 202145-0-10 (270-113) LOWER KNIFE	 302808-0-10 (6378-113) LOWER KNIFE	 302807-0-10 (6378-112) UPPER KNIFE	 CT302865-0-11 UPPER KNIFE, CARBIDE
 202194-0-10 CHAIN CUTTER	 202194-0-11 CHAIN CUTTER	 7190048 LOWER KNIFE	<b>KNIVES PARTS FOR FOMA</b>		 7190047 UPPER KNIFE
			 7190151 UPPER KNIFE		 7160071 CHAIN CUTTER













**KNIVES PARTS FOR SIRUBA**

					
KR35 LOWER KNIFE	KR35C LOWER KNIFE	KR23 UPPER KNIFE	KR23A UPPER KNIFE	KR23C UPPER KNIFE	KS24 CHAIN CUTTER
					
CT18-1 FIXED BLADE	CT19 MOVABLE BLADE	VT04 FIXED BLADE	VT05 MOVABLE BLADE	FBQ30 LOWER KNIFE	FR40 LOWER KNIFE
					
FR34 UPPER KNIFE	FR34B UPPER KNIFE	CRL03 UPPER KNIFE	EC02 MOVABLE BLADE		EC05 FIXED BLADE

**KNIVES PARTS FOR TOYOTA**

					
0252052-141-C FIXED KNIFE	0252052-145-A MOVABLE KNIFE	0252072-145-B MOVABLE KNIFE	2111407-553-B MOVABLE KNIFE	2111417-553-A MOVABLE KNIFE	2111417-556-B FIXED KNIFE

**KNIVES PARTS FOR VARIOUS**



					
TC755 THREAD CUTTER (FOR 1-NEEDLE) FOR FISHBEIN	TC832 THREAD CUTTER (FOR 2-NEEDLE) FOR FISHBEIN	GS1 THREAD CUTTER FOR FISHBEIN	AP18E THREAD CUTTER FOR FISHBEIN	WTC2 THREAD CUTTER FOR FISHBEIN	1. DSK-25 LOWER SIDE KNIFE 2. DSK-27 UPPER SIDE KNIFE FOR FISHBEIN
					
11702 MOVABLE KNIFE	11703 STATIONARY KNIFE	A-10306 BED KNIFE	A-10307 MOVABLE KNIFE	A-10090 MOVABLE KNIFE	A-10091 STATIONARY KNIFE



KNIVES PARTS FOR UNION SPECIAL

					
1348-US (209R) BOTTOM RIGHT KNIFE	1349 (209L) BOTTOM LEFT KNIFE	1351 (208R) TOP RIGHT KNIFE	1352 (208L) TOP LEFT KNIFE	35796B CHAIN CUTTER BLADE , UPPER	35796C CHAIN CUTTER BLADE , LOWER
					
36250 LOWER KNIFE	36270 UPPER KNIFE	39270A UPPER KNIFE	39270E UPPER KNIFE	CT39270E UPPER KNIFE , CARBIDE TIP	39570L UPPER KNIFE
					
39549 LOWER KNIFE	CT39549 LOWER KNIFE , CARBIDE TIP	39549J LOWER KNIFE	CT39549J LOWER KNIFE , CARBIDE	39570 UPPER KNIFE	CT39570 UPPER KNIFE , CARBIDE
					
39570J UPPER KNIFE	CT39570J UPPER KNIFE , CARBIDE	39570K UPPER KNIFE , SERRATED	34770K UPPER KNIFE	39556G CHAIN CUTTER	39556K CHAIN CUTTER
					
39556M CHAIN CUTTING KNIFE COMPLETE	39849 LOWER KNIFE	39870 UPPER KNIFE	1741B CHAIN CUTTER	51449 BOTTOM KNIFE	52349 BOTTOM KNIFE
					
52749A LOWER KNIFE	52770L UPPERER KNIFE	57949 LOWER KNIFE	57770A UPPERER KNIFE	80675 STATIONARY KNIFE	80677 DRIVEN KNIFE

KNIVES PARTS FOR YAMATO

					
2100167 LOWER KNIFE	2110305 LOWER KNIFE	2121111 LOWER KNIFE	22195 LOWER KNIFE	30421 LOWER KNIFE	35285 LOWER KNIFE
					
37472 LOWER KNIFE	37538 LOWER KNIFE	68121 LOWER KNIFE	20496 UPPER KNIFE	32914 UPPER KNIFE	37469 UPPER KNIFE
					
37514 UPPER KNIFE	68184 UPPER KNIFE	20491 UPPER KNIFE	2121107 UPPER KNIFE	35286 UPPER KNIFE	CT37469 UPPER KNIFE
	 1. 2111055 UPPER TRIMMING KNIFE 2. 2111056 LOWER TRIMMING KNIFE				
3100708 MOVABLE TRIMMING KNIFE			20271 CHAIN CUTTER	32706 CHAIN CUTTER	
					
95277 LOWER KNIFE	3101026 LOWER KNIFE	3101633 LOWER KNIFE	3110038 LOWER KNIFE	3201062 LOWER KNIFE	95276 UPPER KNIFE
					
3110037 UPPER KNIFE	3101028 UPPER KNIFE	3101465 UPPER KNIFE	3100512 FIXED KNIFE	3100513 UPPER KNIFE	